

NOVA PRO TIPMATIC SOFT-CLOSE

Detecting and resolving malfunctions

G\*GRASS®

## NOVA PRO TIPMATIC SOFT-CLOSE Detecting and resolving malfunctions



06/20	10		
1	The drawer does not open when active	drawer does not open when activated with pressure.	
	Possible cause	Solution	
1.1	Actuator has not been fitted.	Fit actuator.	
	Actuator is loose.	Press actuator home and check for firm seating.	
	Right/left was mixed up.	Ensure right/left are correct.	
1.2	Tipmatic Soft-close unit has not been fitted.	Fit the unit.	
1.3	Front gap is smaller	Adjust the front gap. Check with a 50 euro cent coin.	+3 mm
1.4	The drawer is blocked by an object.	Remove the object.	
1.5	With high fronts, the activating press must be in the trigger area.	Press the front in the bottom 2/3rds of the front area.  Check that the front is parallel with the cabinet; if necessary, adjust via the tilt angle adjustment.	Max. 400 mm

## **NOVA PRO TIPMATIC SOFT-CLOSE**

Detecting and resolving malfunctions

06/2018






2	Drawer ejects only a few millimetres.		
2			
	Possible cause	Solution	
.1	Synchronisation rod has not been fitted or not been fitted correctly.	Fit synchronisation rod correctly.	
	The synchronisation rod falls out because it is too short.	Request a new synchronisation rod Dimension: Clear cabinet width - 206 mm	
.2	The depth adjustment does not match on both sides.	Adjust the depth adjustment so that right and left are identical, then readjust the front gap.	
3	Drawer does not eject far enough.		
	Possible cause	Solution	
3.1	Ejection force too low.	Increase ejection force by one step  1 = weak  2 = medium  3 = strong	2
4	Drawer ejects too far.		
	Possible cause	Solution	
l.1	Ejection force setting too high.	Reduce the ejection force by one step 1 = weak 2 = medium 3 = strong	3
5	Ejection force cannot be adjusted.		
	Possible cause	Solution	

Touch the drawer to open

and release the trigger spring.



5.0

force.

Strong resistance when adjusting the ejection

## NOVA PRO TIPMATIC SOFT-CLOSE Detecting and resolving malfunctions 06/2018





6	Drawer cannot be closed.		
	Possible cause	Solution	
6.1	Tipmatic Soft-close unit is in a position in which the latch is obstructing.	Push vigorously. A clear clacking sound will be heard. Open the drawer. The drawer can now be closed. "Self-fixing".	1 2
6.2	Front was not let go of early when closing so that the unit triggers again and re-ejects the drawer.	When pushing the drawer shut, let go early on as soon as the spring of the closing unit takes effect.	
6.3	After activating the drawer, it opens by less than 120 mm.	Open drawer by at least 120 mm and then close again.	1 1 20 mm
6.4	Actuator is bent out of the horizontal.	Gently bend the actuator horizontal again.	

Possible cause	Solution	
Drawer too lightly loaded.	Push drawer shut (let go early).	
	Organisation system Tavinea Sorto or Tavinea Optima.	